CHINO

Report Maker 11
Report Composing Software

Instruction Manual
Ver.2.0.0.0

INSTRUCTIONS

Thank you for purchasing Report Maker 11 software.

In order to use this software correctly and safely and to prevent trouble, please read this manual carefully

-- Notice --

CHINO Works America Inc.
Instrumentation, Control and Systems

1. Overview

Report Maker 11 is a software package to compose a report with the data acquired by CHINO`s recorders.

1-1 Main functions and features

* Composing a report with data saved in CHINO`s KR2000,KR2S, KR3000, AL4000 and AH4000.

1-2 Operation environments

Compatible PC   : * .NET Framework 2.0 or later has been installed and runs correctly.

                     * Display resolution: 800 x 600 pixels or more (recommended)

OS   : Windows 2000 (SP4 or later) / XP / Vista / 7 (32.64bit) / 8 (32.64bit) (Windows XP or later recommended)

                     * .NET Framework 4.0 or later (required)

Hard disk   : 150MB or more free space for installation

Memory   : Windows 2000/XP … 1GB recommended (512MB or more)

                     : Windows Vista/7/8 … 2GB or more recommended

CPU   : Windows 2000/XP … 1.5GHz or faster recommended

                     : Windows Vista/7/8   … 2GHz or faster recommended

· "Microsoft" and "Windows" are either trademarks or registered trademarks of Microsoft Corporation, USA.

· "Intel" and "Pentium" are either trademarks or registered trademarks of Intel Corporation, USA.

2. Installation

Double click "setup "from CD to install the software.

3. How to make the report.

3-1: Select from [Start] → [All Programs] → [CHINO] → [Report Maker 11] → [Report Maker 11].

3-2: Click "Browse "button, go to file browsing window.

3-3 Select source files from the browse.

(1) Click the "Folder" button.

(2) Select a drive and folder * If you want to select the file on your desktop, go to C: / Users / (Your user name) / Desktop.

(3) Select a file that you wish to create a report from.

(4) Click the "Add" button. * You can add maximum 5 files with same interval and same channel, recorded apart no further than 1 hour.

(5) Click the "Read "button.

3-4 Report setting

(1) Set the report period.   (2) Select the channels on make the report.

(3) Chart report settings * Lie division is how many divide a 1/4 vertical scale

  (Example 1: line decision: 4, scale: 0 to 2000 => 0, 125, 250, 375, 500, 625,)

  (Example 2: line decision: 5, scale: 0 to 2000 => 0, 100, 200, 300, 400, 500,)

(4) Click "Preview" goes to report preview display.

  * If you wish to save the report on a csv file (read by excel or text) click the "Export to csv" button)

3-5 Printing (1) Click the "Print "button after checking the report chart preview and adding the title and other information.

(2) Set the printing format,(Size, margins)

Letter size print

Letter size PDF

A4 size print

A4 size PDF, and other setting available

Page Setup

Paper

Size: Letter

Source: Automatically Select

Orientation
- Portrait
- Landscape

Margins (inches)

| Left: | 0.4 | Right: | 0.4 |
| Top: | 0.4 | Bottom: | 0.4 |

OK   Cancel

Print

Printer

Name: Adobe PDF   Properties...

Status: Ready

Type: Adobe PDF Converter

Where: Documents*.pdf

Comment: ☐ Print to file

Print range
- ● All
- ○ Pages   from: to:
- ○ Selection

Copies

Number of copies: 1

☑ Collate

OK   Cancel

3-6 Report sample